



Arranging the Cabinets: Start by arranging your assembled cabinets in the order shown on the provide drawings. It's like a fun puzzle, getting everything in just the right place.

Leveling and Aligning the Cabinets: Next, level each cabinet and make sure the front edge of each one is perfectly flush with its neighbor. This step is key for a seamless and professional look.

Securing Cabinets Together: Now, it's time to bond the cabinets together. Use 1 ¼ inch screws to securely screw the cabinets to each other. This will make sure they stay together as one solid unit.

Locating Studs: Grab a stud finder (not included in your kit) to locate the studs in your wall. This is an important step to ensure your cabinets are attached securely to the wall.

Attaching Cabinets to the Wall: Using 2 ½ inch screws, attach the closet to the wall through the Nailer at both the top and bottom of each cabinet, wherever a stud is located. Check out the adjacent diagram for a visual guide on how to do this.

Installation Instructions

Riverside Floor Standing Closet Installation

