

Installing Drawer Boxes and Fronts

Setting Up the Drawer Box: Let's start by placing the drawer box on top of the slides. Make sure the front (the side with the plastic clips on the bottom) is facing outward. Gently push the drawer box back into the cabinet until you hear a satisfying click. That's your cue that it's in place!

Aligning the Drawer Front: Next, use double-sided tape to line up the bottom drawer front with the bottom edge of the Deck. Aim for a tiny gap of about 1/16th of an inch on each side between the drawer front and the outer edge of your gable. It's all about getting that perfect fit!

Pre-Drilling for Screws: With the drawer front held firmly by the tape, carefully slide the drawer box out just enough to work. Now, using a 1/16th inch drill bit, pre-drill holes as close to the sides of the drawer box as you can. This step is crucial, especially for Shaker drawer fronts, to avoid drilling through the panel.

Attaching the Drawer Front: Attach the drawer front using the screws provided. This is where everything starts to come together.

Closing the Drawer: Gently close the drawer to check your work. Everything should look neat and aligned.

Spacing for the Next Drawer Front: Place 1/8-inch spacers on top of the installed drawer front. Then, put the next drawer front on top of the spacers. This ensures even spacing for a professional look.

Repeat the Process: Repeat steps 1-6 for each drawer front until they are all installed. It's a bit repetitive, but the result is worth it!

Riverside Hanging Closet Installation Guide

Measuring and Cutting the Closet Hanging Rod: First things first, measure the width of your closet and subtract a quarter inch from that measurement. This is the length you'll need to cut your hanging rod to ensure a snug fit.

Marking Closet Rod Placement: From the spot where you plan to place the rod, mark a point 1 and 5/8 inches lower. This mark is where your rod will be installed.

Locating the Studs: Time to find those studs! Use a stud finder to locate them in your wall. This is important for securely attaching your rod. After you've put in the first screw, use a level to make sure the rod is straight before adding more screws.

Remember Wall Stud Spacing: Keep in mind that exterior wall studs are typically 24 inches apart, while interior wall studs are usually 16 inches apart. Also, be aware of what's behind your drywall. Sometimes stud finders can be a bit tricky.

Installing the Hanging Rod: Once you're sure the rod is securely in place, it's time to hang your shelf. Carefully hang your assembled shelf on the rod. Tilt the bottom slightly away from the wall to avoid scratches, then slide it into its final position.

Securing the Shelf: Secure the shelf in place by tightening the screws on the hanging bolts. This step ensures everything stays exactly where it should.

Installing Additional Shelves: To install the next shelf, just repeat the same steps. It's the same process, so you'll be a pro in no time!

For more information on how to assemble and install our closet, please visit our website, to watch some of the assembly & installation videos.